English

1. Connecting the Projector



Connect the USB connector to your computer and plug the USB connector to the projector. If you want a brighter display, plug two USB connector to you computer.

Note: It is recommended that you should plug the two USB connectors on the same side of the computer to get the best performance. Please make sure that your computer is capable of supplying sufficient current through the USB ports.

Note: If only one USB port is available, use the Master USB connector.

2. Software Installation

When you first plug in your projector, the built-in software will automatically run. Select "Run AcerDetection.exe" to complete installation.



If the software does not auto run, open your file manager and click on the "Acer DisplayPal" drive and click on the "Acer DisplayPal_Setup.exe" to complete the installation.

Downloaded from www.Manualslib.com manuals search engine



Follow the onscreen instruction and install the application.

After installing the application, you must reboot your computer before using the projector.

Note: It is recommended that you don't use other USB devices (External Optical drive, External HDD device, charging your mobile phone/devices) when using the projector.

3. Running Acer DisplayPal

Double-click on the Acer DisplayPal icon on your Windows Desktop to launch the Acer DisplayPal application.

You will be presented with a dialog box asking you to select the number of USB plugged port.

Downloaded from www.Manualslib.com manuals search engine


Please select how many USB ports are connected:
Master USB only if only one USB port is available.
Master and Slave USB: recommended for higher brightness.
OK
Don't remind me again.

From the application, you can choose 3 mode of display (Mirror, 1:1, and Extended) and also have 4 power modes (Low, Middle, High, and Turbo).

Note: Plug 2 USB connector into you notebook and it should be on the same side. High and Turbo mode are recommended if you use Acer notebooks.

Power Mode	Acer Notebook		Non-Acer Notebook	
	Plug USB x 1 connector	Plug USB x 2 connectors	Plug USB x 1 connector	Plug USB x 2 connectors
Low	Ok	Ok	Ok	Ok
Middle	Ok	Ok	Not guaranteed	Ok
High	Not supported	Ok	Not supported	Not guaranteed
Turbo	Not supported	Ok	Not supported	Not guaranteed

Downloaded from www.Manualslib.com manuals search engine